



316-1821

Perrywood Business Park  
Honeycrook Lane, Salfords  
Redhill, Surrey RH1 5JQ  
Tel: +44 (0) 1737 780790  
Fax: +44 (0) 1737 771908  
E mail: [sales@trident-uk.co.uk](mailto:sales@trident-uk.co.uk)  
Website: <http://www.tridentdisplays.co.uk>

**TRIK C023D-8018-2  
CITIZEN  
4.7" VGA COLOUR  
STN KIT  
USER GUIDE**

## **1. INTRODUCTION**

This document describes the installation and connection details of the Trident kit TRIK-C023D-8018-2 which is the kit of parts for driving the Citizen 4.7" VGA Dual Scan Colour STN LCD panel from an ISA slot of an IBM compatible PC.

The TRIK provides a simple and convenient means of connecting the driver card to the LCD allowing a trouble-free hardware configuration for drive from the PC.

The TRIK consists of the following items,

K6481L-FF	- 4.7" Colour STN
UV665	- PC ISA Driver Card
UV6-3494-T0TB-D30-0.5-A	- Panel Interface Unit
CI-A1A1-A	- 1m Cable
TRIDM 665	- Disks + Manual

## **2. CONNECTION**

Refer to Page 4 for a drawing of the positions of the connections to be made.

**IMPORTANT:-** The LCD, UV665 and UV6-3494-T0TB-D30-0.5-A cards contain CMOS devices and are static sensitive. Full ESD procedures must be observed when handling and connecting these items.

The UV665 card may be plugged into any PC with a 16-bit expansion slot. The previously installed VGA card must be removed (or the motherboard VGA drive disabled).

The UV665 card has a DIL switch, SW1, to set the card for the type of panel in use. This will already be set for this Colour STN panel as follows,

1 – ON, 2 – OFF, 3 – OFF, 4 – ON, 5 – OFF, 6 – OFF

Both ends of the CI-A1A1-A cable are terminated with 44-way D plugs. One end should be plugged into the the 44-way D socket (SKB) on the rear of the UV665 card. The other end should be plugged into the 44-way D socket (SKB) on the Panel Interface Unit (UV6-3494-T0TB-D30-0.5-A).

The Panel Interface Unit is fitted with a flat flexible cable from SK3 which is attached with its blue marker stripe upwards. The other end of this cable should be connected into the LCD via CN1. Pull out the side ears of CN1 and slide home the cable with the blue marker stripe downwards then push in the side ears of CN1 to hold the cable in place.

The Panel Interface Unit has an onboard inverter for driving the backlight of the LCD. The LCD backlight connector should be connected to SK5 on the Panel Interface Unit. This connector is not polarised, however ensure that the connector is fully home and not twisted which could allow a pin to miss the connector socket. To ease possible mounting positions for the Panel Interface Unit, the backlight connections may need to be slightly extended. Note that to avoid backlight dimming or strike problems the backlight connections **MUST NOT** be extended by more than 150mm and high-voltage Silicon sleeved cable **MUST** be used. Refer to Pages 5 and 6 for dimensional drawings of the Panel Interface Unit and the LCD.

**IMPORTANT:-** The inverter circuit generates high voltages and the Panel Interface Unit should not be handled while the power is on. It should also be positioned ensuring that no part of it could possibly touch the LCD, the housing or any other circuitry.

The Panel Interface Unit also contains circuitry to adjust the contrast voltage to the LCD via an onboard pot (VR1) and backlight brightness via another onboard pot (VR2).


In addition, the Panel Interface Unit contains a temperature compensation circuit which is required by the LCD and allows it to be used over its temperature range without constant adjustment of the contrast being required. A thermistor is provided on a flying lead which should be affixed directly to the LCD panel. The body and legs of the thermistor are insulated and should not be allowed to touch the LCD panel or metalwork. An easy method of fixing it is to stick the thermistor to the rear of the LCD (ideally in the middle, away from the backlight hotspots) with insulating tape, one strip above and one strip below the thermistor.

Once all the interconnections have been made the PC may be powered ON. After a few seconds the LCD backlight should come on and the standard PC Boot messages should be displayed on the LCD. VR1 on the Panel Interface Unit may need to be adjusted for preferred contrast. Adjust VR2 to set the required brightness of the backlight.



WARNING:- THIS MODULE GENERATES HIGH VOLTAGES,  
DO NOT TOUCH WHEN POWER IS ON.


4-OFF 3mm  
MOUNTING HOLES



# NOTES

- VR1 - CONTRAST (SK4, EXT. ADJUST OPTION)
- VR2 - BRIGHTNESS (SK6, EXT. ADJUST OPTION)
- THR - THERMISTOR OPTION
- SK5 (SK14) - B/L CONNECTION
- SK7 (SK1, SK2, SK3) - LCD CONNECTION
- SKB (SKC + SKE) - DRIVER CARD CONNECTION

ALL DIMS. IN mm



ISSUE

1

2

3

DATE

29/10/96


DRAWN

FM

APPVD

TRIDENT MICROSYSTEMS LTD.,  
PERRYWOOD BUSINESS PARK,  
HONEYCROCK LANE, REDHILL,  
SURREY, RH1 5JQ.  
TEL. 01737 765900 FAX. 01737 771908.

UV 6-3494  
PANEL INTERFACE UNIT  
(FOR COLOUR STN LCDS)



TRIK C023D-8018-2-UG  
 ISSUE 1.1  
 07/10/99