



SHARP**SERVICE MANUAL**

S30Y114GT15//



(14GT15)



(14GT20)

COLOUR TELEVISION
*Chassis No. UA-1***14GT15**
14GT20
MODELS

In the interests of user-safety (Required by safety regulations in some countries) the set should be restored to its original condition and only parts identical to those specified should be used.

FEATURE

- Favorite Channel
- Full Auto Channel Preset and Auto Channel Skip
- 100-CH Program Memory
- CATV(Hyper Band) Ready <Used Frequency Synthesizer Tuner>
- AVL(Sound Keeper) Function
- Black Stretch Circuit
- On Timer/Sleep Timer/Reminder Timer
- Blue Back Noise Mute
- Front AV-In (14GT-20 Only)
- Rear AV-In/Out Terminals
- Colour Comb Filter (NTSC Only)
- High Contrast Picture
- Hotel Mode
- Front Headphone JACK (14GT-20 Only)
- English / Thai OSD

CONTENTS

	Page	Page
● SPECIFICATIONS	2	
● IMPORTANT SERVICE NOTES	3	
● ADJUSTMENT PRECAUTIONS	4	
● TROUBLE SHOOTING TABLE	27	
● SOLID STATE DEVICE BASE DIAGRAM	31	
● CHASSIS LAYOUT	32	
● WAVEFORMS	34	
● DESCRIPTION OF SCHEMATIC DIAGRAM .	35	
● SCHEMATIC DIAGRAM		
■ INFRARED REMOTE CONTROL UNIT ..	36	
■ TUNER	37	
■ 14GT15, 14GT20 HOTEL MODE APPLICATION	38	
■ HEAD PHONE Unit and CRT Socket Unit	39	
■ MAIN Unit	40	
● BLOCK DIAGRAM	44	
● PRINTED WIRING BOARD ASSEMBLIES ..	49	
● REPLACEMENT PARTS LIST		
■ ELECTRICAL PARTS	54	
■ MISCELLANEOUS PARTS	58	
■ SUPPLIED ACCESSORIES	58	
■ PACKING PARTS	58	
■ CABINET PARTS	59	

WARNING

The chassis in this receiver is partially hot. Use an isolation transformer between the line cord plug and power receptacle, when servicing this chassis. To prevent electric shock, do not remove cover. No user – serviceable parts inside. Refer servicing to qualified service personnel.

SCHEMATIC DIAGRAM: MODEL 14GT20 MAIN Unit

