

SUB-MINIATURE COAX 50/350 SERIES, TPS/TCM JACKS & PLUGS

PL50-1 Shown

CABLE PLUG WRENCH CRIMP	50Ω	3-lug	PL50-	
	50Ω	4-lug		PL50FL-
	50Ω	Threaded		PL350-

BULKHEAD JACK FRONT MOUNT, SOLDER POT	50Ω	3-lug	BJ50
	50Ω	4-lug	BJ50FL
	50Ω	Threaded	BJ350

Mounting Hole: D6.218

PL50C-001 Shown

CABLE PLUG TOOL CRIMP	75Ω	3-lug	UPL50C-	
	50Ω	3-lug		PL50C-
	50Ω	4-lug		PL50CFL-
	50Ω	Threaded		PL350C-

BJ57 Shown

INSULATED BULKHEAD JACK FRONT MOUNT, SOLDER POT	50Ω	3-lug	BJ57
	50Ω	4-lug	BJ57FL
	50Ω	Threaded	BJ357

Mounting Hole: D4.187

PL53-1 Shown

PUSH-ON PLUG WRENCH CRIMP, TPS/TCM	50Ω	3-lug	PL53-
--	-----	-------	--------------

TPS PUSH-ON SOLDER POT PANEL JACK Max Panel Thk: .088	50Ω		BJ51
	50Ω	Ground Lug	BJ51GL

CJ50-1 Shown

CABLE JACK WRENCH CRIMP	50Ω	3-lug	CJ50-	
	50Ω	4-lug		CJ50FL-
	50Ω	Threaded		CJ350-

FEED-THRU JACK	50Ω	3-lug	BJ58
	50Ω	4-lug	BJ58FL
	50Ω	Threaded	BJ358

Mounting Hole: D5.190 / D4.190 (Threaded)

CIRCUIT BOARD JACK	50Ω	3-lug	CBJ50	
	50Ω	4-lug		CBJ50FL
	50Ω	Threaded		CBJ350

BJ59-1 Shown

BULKHEAD JACK WRENCH CRIMP	50Ω	3-lug	BJ59-
	50Ω	4-lug	BJ59FL-
	50Ω	Threaded	BJ359-

Mounting Hole: D4.187

- Refers to cable group table, see pages 68-88. "D" mounting holes are on page 45.