

Type_No	BS_CECC	DESC	Package	Temp_range	Description	Tol
LM120H-15-BSS2	BS9430 F0093		TO39	-55 to +150C	0.5 amp 15 volt negative voltage regulator	4%
LM120K-05			TO3	-55 to +150C	1.5 amp 5 volt negative voltage regulator	4%
LM120K-05-BSS2	BS9430 F0088		TO3	-55 to +150C	1.5 amp 5 volt negative voltage regulator	4%
LM120K-12			TO3	-55 to +150C	1.5 amp 12 volt negative voltage regulator	4%
LM120K-12-BSS2	BS9430 F0088		TO3	-55 to +150C	1.5 amp 12 volt negative voltage regulator	4%
LM120K-15			TO3	-55 to +150C	1.5 amp 15 volt negative voltage regulator	4%
LM120K-15-BSS2	BS9430 F0088		TO3	-55 to +150C	1.5 amp 15 volt negative voltage regulator	4%
LM120MAH-05			TO39	-55 to +150C	0.5 amp 5 volt negative voltage regulator	1%
LM120MAH-12			TO39	-55 to +150C	0.5 amp 12 volt negative voltage regulator	1%
LM120MAH-15			TO39	-55 to +150C	0.5 amp 15 volt negative voltage regulator	1%
LM120MH-05			TO39	-55 to +150C	0.5 amp 5 volt negative voltage regulator	4%
LM120MH-12			TO39	-55 to +150C	0.5 amp 12 volt negative voltage regulator	4%
LM120MH-15			TO39	-55 to +150C	0.5 amp 15 volt negative voltage regulator	4%
LM120R-05			TO66	-55 to +150C	1.5 amp 5 volt negative voltage regulator	4%
LM120R-12			TO66	-55 to +150C	1.5 amp 12 volt negative voltage regulator	4%
LM120R-15			TO66	-55 to +150C	1.5 amp 15 volt negative voltage regulator	4%
LM123AK-05			TO3	-55 to +150C	3.0 amp 5 volt positive voltage regulator	1%
LM123AK-05-883B			TO3	-55 to +150C	3.0 amp 5 volt positive voltage regulator	1%
LM123AK-12			TO3	-55 to +150C	3.0 amp 12 volt positive voltage regulator	1%
LM123AK-15			TO3	-55 to +150C	3.0 amp 15 volt positive voltage regulator	1%
LM123K-05			TO3	-55 to +150C	3.0 amp 5 volt positive voltage regulator	1%
LM123K-05-BSS2	BS9430 F0128		TO3	-55 to +150C	3.0 amp 5 volt positive voltage regulator	1%
LM123K-12			TO3	-55 to +150C	3.0 amp 12 volt positive voltage regulator	1%
LM123K-15			TO3	-55 to +150C	3.0 amp 15 volt positive voltage regulator	1%
LM137-220M			TO220 Metal Iso	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137-220M-B			TO220 Metal Iso	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137-220M-ISO			TO220 Metal Iso	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137-220SM			TO220 Ceramic SM	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137-220SM-B			TO220 Ceramic SM	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137-SM			TO220 Ceramic SM	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137.TO39			TO39	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137.TO66			TO66	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137AG			TO257	-55 to +150C	1.5 amp variable negative voltage regulator	1%
LM137AHV-220M			TO220 Metal	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	1%
LM137AHV-220M-ISO			TO220 Metal	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	1%
LM137AHVG			TO257	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	1%
LM137AHVK			TO3	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	1%
LM137AHVR			TO66	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	1%
LM137AK			TO3	-55 to +150C	1.5 amp variable negative voltage regulator	1%
LM137AR			TO66	-55 to +150C	1.5 amp variable negative voltage regulator	1%
LM137ASM			TO220 Ceramic SM	-55 to +150C	1.5 amp variable negative voltage regulator	1%
LM137G			TO257	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137H-883B			TO39	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137H-BSS2	BS9430 F0386		TO39	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137H-OS2			TO39	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137HVG			TO257	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	4%
LM137HVK			TO3	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	4%
LM137HVR			TO66	-55 to +150C	1.5 amp variable negative voltage regulator - 60 v differential	4%
LM137IG			TO257	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137K			TO3	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137K-883B			TO3	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137K-BSS2	BS9430 F0389		TO3	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM137MAH			TO39	-55 to +150C	0.5 amp variable negative voltage regulator	4%
LM137MAHVH			TO39	-55 to +150C	0.5 amp variable negative voltage regulator - 60 v differential	4%
LM137MH			TO39	-55 to +150C	0.5 amp variable negative voltage regulator	4%
LM137MHVH			TO39	-55 to +150C	0.5 amp variable negative voltage regulator - 60 v differential	4%
LM137R			TO66	-55 to +150C	1.5 amp variable negative voltage regulator	4%
LM138AK			TO3	-55 to +150C	5 amp variable positive voltage regulator	1%
LM138AK-883B			TO3	-55 to +150C	5 amp variable positive voltage regulator	1%
LM138K			TO3	-55 to +150C	5 amp variable positive voltage regulator	4%
LM140AG-05			TO257	-55 to +150C	1 amp 5 volt positive voltage regulator	1%
LM140AG-12			TO257	-55 to +150C	1 amp 12 volt positive voltage regulator	1%
LM140AG-15			TO257	-55 to +150C	1 amp 15 volt positive voltage regulator	1%
LM140AK-05			TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	1%
LM140AK-05-883B			TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	1%
LM140AK-05-BSS2	BS9430 F0107		TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	1%
LM140AK-12			TO3	-55 to +150C	1 amp 12 volt positive voltage regulator	1%
LM140AK-12-BSS2	BS9430 F0107		TO3	-55 to +150C	1 amp 12 volt positive voltage regulator	1%
LM140AK-15			TO3	-55 to +150C	1 amp 15 volt positive voltage regulator	1%
LM140AK-15-BSS2	BS9430 F0107		TO3	-55 to +150C	1 amp 15 volt positive voltage regulator	1%
LM140AR-05			TO66	-55 to +150C	1 amp 5 volt positive voltage regulator	1%
LM140AR-12			TO66	-55 to +150C	1 amp 12 volt positive voltage regulator	1%
LM140AR-15			TO66	-55 to +150C	1 amp 15 volt positive voltage regulator	1%
LM140G-05			TO257	-55 to +150C	1 amp 5 volt positive voltage regulator	4%
LM140G-12			TO257	-55 to +150C	1 amp 12 volt positive voltage regulator	4%
LM140G-15			TO257	-55 to +150C	1 amp 15 volt positive voltage regulator	4%
LM140H-05-883B			TO39	-55 to +150C	1 amp 5 volt positive voltage regulator	4%
LM140H-12-883B			TO39	-55 to +150C	1 amp 12 volt positive voltage regulator	4%
LM140H-15-883B			TO39	-55 to +150C	1 amp 15 volt positive voltage regulator	4%
LM140K-05			TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	4%
LM140K-05-883B			TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	4%
LM140K-05-BSS2	BS9430 F0102		TO3	-55 to +150C	1 amp 5 volt positive voltage regulator	4%