

STANDARD TWINAX/TRIAX PATCHING

PL71L-9 Shown

TWINAX PATCH PLUG **PL71L- Δ**

DASH NO.	CONNECTOR TYPE			A DIM	B DIM
	P1 & P2	P3			
-1	BJ20	BJ77		1.166	1.988
-2	PL21	BJ77		1.185	2.177
-3	PL21	BJ77		1.185	2.256
-4	BJ20	BJ77		1.166	1.988
-5	BJ20	PL3155		1.166	2.385
-6	BJ20	PL375		1.166	2.666
-7	UPL21	BJ77		1.186	2.256

FIXED PARALLELING JACKS **305-0138**-(see chart)

2 BNC JACKS TO 1 TRB JACK
2 BNC PLUGS TO 1 TRB JACK
2 BNC PLUGS TO 1 TRB JACK

TWINAX PATCH CORD **PTWL-L-Z**

TRIAx **PTRL-L-Z**

TWINAX DUAL PATCH CORD **DPLTWLS-L-Z**

LPTWL-78 Shown

TWINAX LOOPING PLUG **LPTWL-Z**

TRIAx **LPTRL-Z**

TWINAX PATCH JACK **J72L**

TRB 3-LUG

JSISM-60

JSISM-120

FRONT-LOADING MODULAR PANELS

FOR USE WITH J74MST-R PATCH JACKS (PG. 57)

PANEL DIMENSIONS	MODULES/PANELS	JACKS/MODULE	JACKS/PANEL	PART NUMBER
19" X 3.483"	10	2	20	JSISM-60
19" X 2.34"	10	4	40	JSISM-120

R-Resistance (1/2 W1%), Z- Denotes Cable Impedance. Δ - Refers to Cable Group Table, see pages 91-133. Standard and Sub-miniature Panels, see pages 51-54