

K

T&B Data & Communication Products

Coaxial Connectors

AT2JB

AT2J

Transitional adaptor between coax and modular connectors.

TNC Adaptors

Cat. No.	Description
AT2J*	TNC Adaptor
AT2JB	Bulkhead Adaptor

* Requires use of TCAWBH adaptor for use with wallplate.

Baluns

Cat. No.	Description	Pins
TCB11J	RJ11 Modular Jack to Coax Jack	3-4
TCB45J	RJ45 Modular Jack to Coax Jack	4-5
TCB11P	RJ11 Modular Jack to Coax Plug	3-4
TCB45P	RJ45 Modular Jack to Coax Plug	4-5

TCB11J

BNC Coax Jack

RJ11 Telephone Jack

27/32

19/32

1-13/32

1-7/8

TCB11J
THOMAS & BETTS
CORPORATION
HARTMAN, NJ

TCB45J

BNC Coax Jack

RJ45 Telephone Jack

13/16

3/4

1-9/32

1-3/4

TCB45J
THOMAS & BETTS
CORPORATION
HARTMAN, NJ

TCB11P

BNC Coax Plug

RJ11 Telephone Jack

27/32

19/32

1-13/32

2-1/16

TCB11P
THOMAS & BETTS
CORPORATION
HARTMAN, NJ

TCB45P

BNC Coax Plug

RJ45 Telephone Jack

13/16

3/4

1-9/32

2-3/16

TCB45P
THOMAS & BETTS
CORPORATION
HARTMAN, NJ

Thomas & Betts

K/952