

PC905

Long Creepage Distance Photocoupler with Built-in Voltage Detection Circuit

- * Lead forming type (I type) is also available. (PC905I)
- ** TÜV (DIN-VDE0884) approved type is also available as an option.

■ Features


1. Built-in voltage deviation detection circuit
2. Long creepage distance type
(Creepage distance : 8mm or more)
3. Conforms to European Safety Standard
(Internal insulation distance : 0.5mm or more)
4. High collector-emitter voltage (V_{CEO} : 70V)
5. High isolation voltage between input and output (V_{iso} : 5 000V_{rms})
6. Recognized by UL, file No. E64380
Approved by BSI (BS415 : No. 6990, BS7002 : No. 7567)
Approved by SEMKO No. 963501101
Approved by DEMKO No. 392592

■ Applications

1. Switching power supplies

■ Outline Dimensions

(Unit : mm)



■ Absolute Maximum Ratings

($T_a = 25^\circ\text{C}$)

	Parameter	Symbol	Rating	Unit
Input	Anode current	I_A	50	mA
	Anode voltage	V_A	30	V
	Reference input current	I_{REF}	10	mA
	Power dissipation	P	250	mW
Output	Collector-emitter voltage	V_{CEO}	70	V
	Emitter-collector voltage	V_{ECO}	6	V
	Collector current	I_C	50	mA
	Collector power dissipation	P_C	150	mW
Total power dissipation		P_{tot}	350	mW
*1 Isolation voltage		V_{iso}	5 000	V _{rms}
Operating temperature		T_{opr}	- 25 to + 85	$^\circ\text{C}$
Storage temperature		T_{stg}	- 40 to + 125	$^\circ\text{C}$
*2 Soldering temperature		T_{sol}	260	$^\circ\text{C}$

*1 40 to 60% RH, AC for 1 minute

*2 For 10 seconds

Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7 Anode Current vs. Ambient Temperature




Fig. 8 Input Power Dissipation vs. Ambient Temperature




Fig. 9 Collector Power Dissipation vs. Ambient Temperature




Fig.10 Power Dissipation vs. Ambient Temperature




Fig.11 Relative Current Transfer Ratio vs. Ambient Temperature




Fig.12 Collector Dark Current vs. Ambient Temperature




Fig.13-a Anode Current vs. Reference Voltage




Fig.13-b Anode Current vs. Reference Voltage




Fig.14 OFF-state Anode Current vs. Ambient Temperature




Fig.15 Reference Voltage vs. Ambient Temperature




Fig.16 Reference Input Current vs. Ambient Temperature




Fig.17 Reference Voltage Change vs. Anode Voltage






Fig.18-a Voltage Gain (1) vs. Frequency




Test Circuit for Voltage Gain (1) vs. Frequency



$$A_{V1} = 20 \log \frac{V_o}{V_{in}}$$

Fig.18-b Voltage Gain (2) vs. Frequency



Test Circuit for Voltage Gain (2) vs. Frequency





Fig.19 Anode Current vs. Load Capacitance



Test Circuit for Anode Current vs. Load Capacitance




Fig.20 Collector-emitter Saturation Voltage vs. Ambient Temperature





Fig.21 Current Transfer Ratio vs. Anode Current



■ Precautions for Use

Handle this product the same as with other integrated circuits against static electricity.

- As for other general cautions, refer to the chapter "Precautions for Use"