None

None

None

1

1

1



## **General Description**

The MAX1760 evaluation kit (EV kit) is a fully assembled and tested surface-mount circuit board that contains a boost switching-regulator circuit. The EV kit provides a regulated +3.3V output at up to 800mA of current. The input voltage range is +0.7V to +5.5V. However, the output voltage will rise above the regulation point for input voltages exceeding 3.3V. A one- or two-cell battery input can also be used to power the EV kit.

The MAX1760 features an internal N-channel MOSFET switch, a synchronous rectifier, and a pin-selectable forced PWM mode. The MAX1760 EV kit demonstrates low quiescent current and power efficiency up to 96%, thus increasing battery life. Operation at 1MHz allows the use of tiny surface-mount components.

MAX1760 PC board

MAX1760 data sheet

MAX1760 EV kit data sheet

### **Features**

- +0.7V to +5.5V Input Voltage
- +3.3V Output Voltage
- Internal Synchronous Rectifier Provides up to 96% Efficiency
- Output is Adjustable with External Resistors
- Up to 800mA Output
- On-Chip N-Channel Switch
- 1µA Shutdown Current
- 1MHz Switching Frequency
- Fixed-Frequency PWM Operation
- Surface-Mount Components
- Fully Assembled and Tested

DESIGNATION	QTY	DESCRIPTION	PART	
C1	1	33µF, 16V, low-ESR electrolytic cap	MAX1760EVKIT	
		Sanyo 16TPC33M		
C2	1	100µF, 6.3V, low-ESR electrolytic cap		
		Sanyo 6TPC100M		
C3	1	1µF, 10V, X5R ceramic cap (0805)	SUPPLIER	
		Taiyo Yuden LMK212BJ105MG	Coilcraft	
C4	1	0.68µF, 10V, X5R ceramic cap (0805) Taiyo Yuden LMK212BJ684KG	Nihon USA	
			Sanyo USA	
C5	1	0.22µF, 25V, X7R ceramic cap (1206) Taiyo Yuden TMK316BJ224KF	Taiyo Yuden	
			<i>Note:</i> Please indicate contacting these cor	
C6	0	Not installed (0805)		
D1	1	Not installed, Nihon EP10QY03		
L1	1	3.3µН, 1.4A inductor	The MAX1760 F	
		Coilcraft DO1606T-332	Follow these steps	
R3	1	4.7Ω ±5% resistor (0805)	output. Do not tur nections are com	
R1, R2, R4, R5	0	Not installed (0805)		
U1	1	Maxim MAX1760EUB (10-pin µMAX)	1) Connect a +1	
JU1, JU2	2	3-pin headers	VIN pad. Con	
None	2	Shunts (JU1, JU2)	pad.	

#### **Component List**

## **Ordering Information**

PART	TEMP. RANGE	IC PACKAGE
MAX1760EVKIT	0°C to +70°C	10 µMAX

## **Component Suppliers**

SUPPLIER	PHONE	FAX
Coilcraft	847-639-6400	847-639-1469
Nihon USA	661-867-2555	661-867-2698
Sanyo USA	619-661-6835	619-661-1055
Taiyo Yuden	408-573-4150	408-573-4159

e that you are using the MAX1760 when mponent suppliers.

## **Quick Start**

/ kit is fully assembled and tested. s to verify board operation for a +3.3V n on the power supply until all conpleted.

- .1V to +3.2V DC power supply to the nect the supply ground to the GND
- 2) Connect a voltmeter to the VOUT pad.
- 3) Verify that jumper JU1 ( $\overline{ON}$ ) has a shunt across pins 2 and 3 and jumper JU2 (CLK/SEL) has a shunt across pins 1 and 2.
- 4) Turn on the power supply and verify that the main output is +3.3V.

Maxim Integrated Products 1

For free samples and the latest literature, visit www.maxim-ic.com or phone 1-800-998-8800. For small orders, phone 1-800-835-8769.

## 

# **MAX1760 Evaluation Kit**

# SHUNT<br/>LOCATION $\overline{ON}$ PINMAX1760 OUTPUT1-2Connected to VOUTShutdown mode,<br/>VOUT = VIN - VDIODE2-3Connected to GNDMAX1760 enabled,<br/>VOUT = +3.3V

## Table 1. Jumper JU1 Functions

## **Detailed Description**

The MAX1760 EV kit contains a boost switching-regulator circuit that provides a +3.3V output. The circuit requires a +0.7V to +3.2V input voltage to maintain regulation. The output supplies up to 800mA as configured.

The output voltage can also be adjusted from +2.5V to +5.5V with external resistors. The MAX1760 EV kit permits jumper-selectable operational modes: normal mode, forced PWM mode, and forced PWM mode with the internal oscillator synchronized to an external clock.

#### **Jumper Selection**

Two PC board jumpers provide the user with various operating configurations. Shutdown mode and CLK/ SEL mode are configurable via jumpers.

#### Shutdown Mode

The MAX1760 EV kit features a shutdown mode that reduces the IC's quiescent current to  $1\mu$ A (typ), preserving battery life. The 3-pin jumper, JU1, selects the shutdown mode for the circuit. Table 1 lists the selectable jumper options.

#### CLK/SEL Operating Mode

Jumper JU2 controls the CLK/SEL pin operating mode. Options include low-noise forced PWM mode, normal mode, and an external clock source to drive the CLK/SEL pin. The external clock source must operate in the 500kHz to 1200kHz range. Table 2 lists the CLK/SEL jumper options.

**Evaluating Lower Startup Input Voltages** The MAX1760 EV kit can operate from DC supply voltages down to +0.7V. Install Schottky diode, D1, to ensure startup when  $V_{IN}$  is below +1.1V. Refer to the *Output Diode* section in the MAX1760 data sheet for instructions on selecting D1. D1 is not needed for input voltages above +1.1V.

## Table 2. Jumper JU2 Functions

SHUNT LOCATION	CLK/SEL PIN	OPERATING MODE
1-2	Connected to VOUT	Forced PWM mode: PWM operation at all loads
2-3	Connected to GND	Normal mode: PFM at light load and PWM at medium to heavy load
None	Clock connected to CLK/SEL pad	PWM mode synchro- nized to external 500kHz to 1200kHz range clock

#### **Evaluating Other Output Voltages**

The output is set to +3.3V by grounding the feedback pin (FB). To generate output voltages other than +3.3V (+2.5V to +5.5V), cut open the PC board trace shorting R2, and select the external voltage-divider resistors (R1, R2). Refer to the *Setting the Output Voltage* section in the MAX1760 data sheet for instructions on selecting R1 and R2. To maintain a regulated output, the input voltage range is +0.7V to VOUT to maintain a regulated output.

#### **Evaluating Other Current Limits**

The EV kit inductor current limit can be set from 625mA to 1250mA. The EV kit is factory-configured for 1250mA. To set the current limit to 625mA, cut open the PC board trace shorting R4, and insert 1M $\Omega$  resistors for R4 and R5. Refer to the *Setting the Switch Current and Soft Start* section of the MAX1760 data sheet to select other R4 and R5 values.

#### **Enabling Soft-Start**

The MAX1760 soft-start feature will limit inrush current during startup. Installing capacitor C6 activates this feature. Refer to the *Setting the Switch Current and Soft-Start* section in the MAX1760 data sheet for instructions on selecting C6 values.

M \X | M

# **MAX1760 Evaluation Kit**



Figure 1. MAX1760 EV Kit Schematic



## **MAX1760 Evaluation Kit**



Figure 2. MAX1760 EV Kit Component Placement Guide— Top Silkscreen



Figure 4. MAX1760 EV Kit PC Board Layout—Component Side



Figure 3. MAX1760 EV Kit Component Placement Guide— Bottom Silkscreen



Figure 5. MAX1760 EV Kit PC Board Layout—Solder Side

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

Printed USA

4

\_\_\_\_Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600

© 2000 Maxim Integrated Products

**MAXIM** is a registered trademark of Maxim Integrated Products.