



The Future of Analog IC Technology™

# EV2364DF-01A

1.5A, 23V, 1.4MHz Dual Step-Down Converter Evaluation Board

## DESCRIPTION

The EV2364DF-01A is an evaluation board for the MP2364, a dual output, monolithic step-down switch mode converter with built-in internal power MOSFETs. It achieves 1.5A continuous output current for each output over a wide input supply range with excellent load and line regulation.

The MP2364's current mode operation provides fast transient response and eases loop stabilization.

Its fault protection includes cycle-by-cycle current limiting and thermal shutdown. In shutdown mode the regulator draws 40µA of supply current.

## ELECTRICAL SPECIFICATIONS

Parameter	Symbol	Value	Units
Input Voltage	V <sub>IN</sub>	4.75 to 23	V
Output Voltage A	V <sub>OUTA</sub>	3.3	V
Output Voltage B	V <sub>OUTB</sub>	2.5	V

## FEATURES


- 1.5A Current for Each Output
- Ceramic Input and Output Capacitors
- Up to 90% Efficiency
- Fixed 1.4MHz Frequency
- Wide 4.75V to 23V Operating Input Range

## APPLICATIONS

- Distributed Power Systems
- I/O and Core Supplies
- DSL Modems
- Set Top Boxes
- Cable Modems

"MPS" and "The Future of Analog IC Technology" are Trademarks of Monolithic Power Systems, Inc.


## EV2364DF-01A EVALUATION BOARD



(L x W x H) 2.2" x 1.6" x 0.4"  
(5.5cm x 4.1cm x 1.0cm)

Board Number	MPS IC Number
EV2364DF-01A	MP2364DF

### Efficiency vs Load Current





## PRINTED CIRCUIT BOARD LAYOUT




Figure 1—Top Silk Layer




Figure 2—Top Layer




Figure 3—Bottom Layer

## QUICK START GUIDE

The output voltages of this board are set to 3.3V (V<sub>OUTA</sub>) and 2.5V (V<sub>OUTB</sub>). The board layout accommodates most commonly used inductors and output capacitors.

1. Attach the positive and negative ends of the first load to the V<sub>OUTA</sub> and GND pins, respectively. If using both outputs, attach the positive and negative ends of the second load to the V<sub>OUTB</sub> and GND pins, respectively.
2. Preset the power supply output to 4.75V to 23V and turn it off.
3. Connect the positive terminal of the power supply output to the VIN pin and the negative terminal of the power supply output to the GND pin.
4. Turn the power supply on. The MP2364 will automatically startup.
5. To use the Enable function, apply a digital input to the EN pin. Drive EN higher than 2.5V to turn on the regulator and less than 0.7V to turn it off.
6. The output voltages V<sub>OUTA</sub> and V<sub>OUTB</sub> can be changed by varying R1 and R4, respectively. Calculate the new values by the following formulae:

$$R1 = R6 \times \left( \frac{V_{OUTA}}{0.92} - 1 \right)$$

$$R4 = R3 \times \left( \frac{V_{OUTB}}{0.92} - 1 \right)$$

Where R6 = 10kΩ and R3 = 10kΩ

Example:

For V<sub>OUTA</sub> = 3.3V:

$$R1 = 10k\Omega \times \left( \frac{3.3}{0.92} - 1 \right) = 25.9k\Omega$$

Therefore, use a 25.5kΩ standard 1% value resistor.

**NOTICE:** The information in this document is subject to change without notice. Please contact MPS for current specifications. Users should warrant and guarantee that third party Intellectual Property rights are not infringed upon when integrating MPS products into any application. MPS will not assume any legal responsibility for any said applications.