



# **POWER ANALYZER 3390**

Power measuring instruments





www.hioki.com

# **Power Analyzer 3390**


# Portable design incorporates new-generation measurement technologies

Demand for high-accuracy, wide-band, high-speed data processing with safe and simultaneous measurement over several channels is fully met with a single unit – improving efficiency for applications to evaluate new energies, inverters and motors

3390 Power Analyzer - Your Best Partner in an Era of New Energies

# ☐ Features

- Newly developed Power Analyzing Control Engine Technology processes all measurement data at high speeds and with excellent accuracy
- ♦ Maximum accuracy of ±0.16% (when combined with the AC/DC Current Sensor 9709)
- Priimary and secondary sides of inverters can be measured simultaneously, while also measuring inverter noise
- Wide variety of motor evaluation and analysis functions on-board
- ♦ Easy-to-read, crystal-clear, multi-colored data display on a 9" WVGA color screen



# 1 4-channel isolated input and current sensor method

- Choose wiring from single-phase two-wire to three-phase four-wire
- Measure the primary and secondary sides of inverters simultaneously
- Synchronize the measurements of multiple 3390s

# 3 All data updated at 50ms\*

- Rapid processing achieved with the HIOKI proprietary Power Analyzing Control Engine Technology
- 50ms data refresh rate for all measurements unaffected by settings restraints
- Synchronize the measurements of multiple 3390s

Automatic update rate eliminates the need of switching for low-frequency measurements (50ms data refresh rate does not apply to waveform and noise analysis)

2 Basic accuracy of Model 3390: ±0.1%

Basic measurement range: DC, 0.5 Hz to 5 kHz

(Frequency bandwidth: DC, 0.5 Hz to 150 kHz)

Effective input range: 1% to 110%

- High accuracy, wide band, and wide dynamic range
- Also measure the secondary side of DC inverters in conjunction with a variety of HIOKI current sensors

# 4 Multiple interfaces

- LAN and USB communication (with free dedicated software)
- Automatically save interval measurement data to a CF card (When saving manually, measured data and waveform data can be saved directly to the CF card and USB memory)

## Simple and safe measurements using a variety of HIOKI current sensors

- Choice of sensors include easy-to-measure AC and AC/DC clamp-on sensors and feed-through current sensors for high-accuracy measurements
- Current sensor design allows for safe and efficient testing
- Immune to in-phase noise effects when measuring inverters



## 6 Ideal for Motor Evaluation and Analysis

• Use of the MOTOR TESTING OPTION 9791 (or 9793) allows torque meter output and rotation input, and facilitates motor power measurement





Terminal A Terminal B Terminal Z

Motor options

D/A output terminal (Waveform output terminal)

## HTTP server function available with free dedicated PC software


- HTTP server function through web browser allows easy remote operation
- Free dedicated PC application can be downloaded from the HIOKI website Collect data and operate the 3390 remotely by connecting it to a PC via LAN or USB

# LAN SYNC OUT SYNC IN Mini USB RS-232C

# Waveform Output and 16 Channel D/A output

- Use the D/A OUTPUT OPTION 9792 to update data every 50ms and output up to 16 items in analog format
- Also output the voltage and current waveforms for each channel (using 1 to 8 channels)

(Waveforms are output at 500 kS/s and sinusoidal waveforms can be represented accurately at up to 20 kHz)



# Multiple 3390 units can be linked for synchronized operation

- Connect up to four 3390s and synchronize their clocks and measurement timing for multiple-channel measurements (using the SYNC terminal and Connection Cable 9683)
- Use dedicated application software to conduct synchronized operations for up to 4 units and obtain all the measurement data

# Perfectly sized for Portability and System Installation

- Compact and lightweight Ideal for field measurements
- Designed for rack mounts



# Connect an External Printer or Thermometer

- Print measurements on site by connecting the Printer 9670 (option)
- Data from temperature measurements taken with an external

thermometer aids in motor evaluation


Connecting the 3440 SeriesTemperature HiTESTER (via the RS-232C interface) also allows temperature data to be collected simultaneously



# **Extra-Large Screen Expands Possibilities**

Capture measured data and waveforms at a glance utilizing a variety of display options


(The 9" color LCD can display up to 32 data parameters)



## All measurements start with just a connection

Wiring check function prevents connection errors

Display connection and vector diagrams on the Connection Check screen Improve efficiency and reliability while saving time in wiring even for three-phase measurements



Display just the required data in an easy-to-read graphic interface on the Select and Display screen Screen\_displaying\_32,\_16\_8, or\_4\_items

Display items can be set individually for each selected screen

Data can be read quickly and easily by just switching between the screens





# All data is processed in parallel simultaneously. A wealth of data analysis functions all built-in and ready to use.


Add the MOTOR TESTING OPTION 9791 (9793) to get extra functionality, and just switch between the screens to check all data.

- 1. RMS and MEAN values, and AC, DC, and fundamental waveform components can be measured and displayed simultaneously
- 2. Waveform display: Inverter waveforms can be observed at a high speed of 500 kS/s
- 3. Harmonic analysis: Up to 100th order
- 4. Inverter noise analysis: 100 kHz (FFT analysis)
- 5. X-Y graph function: For multifaceted analysis










# 



# Measure the primary and secondary sides of inverters

(Performance evaluation of motors and inverters)


Accurately and easily measure the power of inverters and motors for a wide range of measurements, from research and development to field tests

#### **Advantages**

- 1. Isolated input of voltage and current lets you measure the power on the primary and secondary sides of inverters simultaneously.
- 2. Using a non-invasive current sensor makes the connection simple and easy. A vector diagram display ensures connections are checked.

#### Proprietary HIOKI Technology

- 3. Accurately measure the Fundamental wave voltage and current values related to the motor axis output with confidence
- 4. All data is measured simultaneously and updated every 50 ms.
- 5. In addition to the harmonic analysis required to evaluate the inverter control, noise components can also be measured at the same time ideal for determining the leakage of inverter noise
- 6. Use of a current sensor reduces the effect of in-phase noise from inverters when measuring the power




# 2 PC measurements and multiple-unit synchronized measurements

 Dedicated application software allows you to perform PC measurements right out of the box

LAN and USB compabitility facilitates efficient data collection and remote operation. Bundled application software allows you to control up to 4 units.

Acquire all data even when multi-unit measurements are performed.
 Two units can be connected using the CONNECTION CABLE 9683 (option) to synchronize the internal clocks and control signals.

Interval measurements with the two units allow the acquisition of perfectly synchronized data, making it easy to collect completely harmonized data with a CF card without using a PC.



#### ■ What's so special about inverter motors?

Inverter motors are indispensable as the power source of industrial equipment. The rotation of an induction motor depends on the input frequency, so if this input frequency can be made variable, the rotation can be controlled freely. Development of a frequency conversion technology called an inverter has made it possible to freely control the rotation of motors.

In recent years, the mainstream inverter control method is the PWM (Pulse-width Modulation) method.

#### • What is the PWM method?


A pseudo sinusoidal waveform (fundamental wave) is comprised of a pulse train called a carrier frequency (at about several kHz to 15 kHz) as the fundamental wave frequency that determines the rotation of a motor.

#### Performance evaluation and electrical measurement of motor

The axis output of a motor is closely related to the fundamental wave frequency to be input, so an accurate measurement of this fundamental wave component is required to evaluate the input characteristics.

#### Conventional measurement method

Traditional methods use the average rectified RMS indication (Mean) in order to obtain a component value close to the fundamental wave frequency from a pseudo sinusoidal waveform (fundamental wave + carrier wave) to be input. To measure an accurate fundamental component, frequency analysis was required; however, the conventional processing method was not practical because it could barely perform real-time measurements with FFT as a result of the limited computing power.



• The 3390 is capable of measuring the fundamental wave component accurately The 3390 performs this frequency analysis using high-speed harmonic computation processing at an interval of 50 ms and displays the true fundamental wave component.

# 3 To make the best of inverter motor measurements:

· Parameters critical to the measurement of motor inputs (outputs on the secondary side of inverters) can be measured and displayed simultaneously.

Display item	Measurement details
rms value	RMS value of fundamental wave + carrier wave components
mn value	RMS value (mean value) close to the fundamental wave component
fnd value	True fundamental wave component
thd value	Displays the distortion factor of measured waveform
unb value	Displays the balance between phases
±pk value	Maximum positive/negative values of waveform that is being measured
dc value	Displays a DC component harmful to the motor
ac value	RMS value obtained by removing the DC component from the RMS value
f value	Frequency of each phase

# 4 Clearly display efficiency and loss of inverters

· Efficiency and loss measurement function built-in

The operating efficiency and power loss of an inverter can be displayed when measuring the inputs and outputs of the inverter simultaneously.



# 6 Harmonic measurement indispensable for inverter evaluation

• 4-channel simultaneous harmonic analysis function built-in (Performed simultaneously with power measurement)

Harmonic analysis is essential for the development and evaluation of inverters Synchronized to the fundamental wave frequency from 0.5 Hz to 5 kHz Harmonic analysis up to the 100th order can be performed simultaneously with power measurement.



# 

# 5 X-Y graph display lets you check the dynamic aracteristics of inverters

• X-Y graph display function built-in (X-axis: 1 item, Y-axis: 2 items)

By simply specifying the voltage for the X-axis and the power consumption and efficiency for the Y-axis, you can display the dynamic characteristics of a motor in real time.



# **7** Evaluation of the troublesome noise of inverters

• Noise measurement function built-in (1-channel measurement: Performed simultaneously with power measurement and harmonic analysis)

Noise components at up to 100 kHz can be read while looking at the measured waveforms Simultaneously display the top 10 point frequency and voltage/current levels



# 8 Waveforms can be observed at 500 kS/s, and fundamental waves can also be checked

Waveform monitoring function fully supported

Display the voltage and current waveforms being measured

The carrier frequency components of an inverter are also displayed in real time

Filter function

A filter function is used to remove the carrier frequency components from the inverter, and fundamental wave frequency waveforms can be checked in the waveform display.

\* The filter function is reflected in the measured values. Please be careful when you switch to the function during measurement.

Waveform monitoring of carrier frequency

When the 500 Hz filter is turned ON

# Geared for the latest motor evaluation and analysis of Hybrid Electric Vehicles, Electric Vehicles and the like


Drive the research and development of three-phase inverter motors with high accuracy and high-speed measurements

#### **Advantages**

- 1. Use of the MOTOR TESTING OPTION 9791 (9793) lets you perform a total evaluation of inverter motors
- 2. The voltage, torque, rotation, frequency, slip, and motor power required for motor analysis can be measured with one unit
- 3. Current sensors make the connection simple. In addition, use of the AC/DC CURRENT SENSOR 9709 enables measurements with superior accuracy

#### Proprietary HIOKI Technology


- 4. All data is measured simultaneously and updated every 50 ms. Data collection and characteristics tests can be performed at the industry's fastest speed
- 5. Evolution of electrical angle measurements critical to motor analysis has made it possible to perform more accurate measurements using an incremental encoder
- 6. Harmonic analysis at 0.5 Hz to 5 kHz without the need for an external timing mechanism
- 7. Built-in digital anti-aliasing filter (AAF) lets you measure the broadband power on the secondary side of inverters to make accurate harmonic analyses



# 1 Evaluate high-performance vector control inverters:

- Measurements of fundamental wave voltage and current and their phases based on an accurate harmonic analysis are indispensable to motor analysis
- Support of an incremental encoder allows detecting synchronization signals from a motor easily and accurately

Electrical angle measurements are indispensable for dynamic characteristics analysis of motors. The 3390 can conduct FFT analyses synchronized to rotation pulses from the tachometer and the motor induced voltage, and the A-phase and Z-phase pulse inputs that allow measuring and detecting the origin of the motor more simply and accurately – fully meeting the needs of the latest motor analysis tests.



# Encoder Z-phase signal Voltage / current waveform

#### ■ Application 1: "Electrical angle measurement"

- $\circ$  The voltage / current fundamental wave component " $\theta$ " from the machine angle origin can be calculated by performing harmonic analysis of motor input voltage / current by synchronizing to the A-phase signal and z-phase signal of an encoder.
- A function to perform zero compensation for this phase angle when a motor induced voltage is generated can be used to measure the voltage and current phase (electrical angle) in real time based on the induced voltage when the motor is started.

#### ■ The importance of measuring the electrical angle of synchronous motors

The key to the performance of high-performance low-fuel consumption vehicles represented by HEV and EV is the synchronous motor that is used as the power source. The synchronous motor is finely controlled by alternating signals generated by an inverter device (DC to AC conversion) using the electricity from batteries.

#### • What is a synchronous motor?

A synchronous motor rotates in synchronization with the AC frequency. Structurally, the motor is turned by the rotating force at the magnetic pole of the rotator (rotator magnetic pole), which is generated by the rotating magnetic field generated by applying an alternating current to the magnetic field (stator magnetic pole). The rotation speed is synchronized to the speed of the rotating magnetic field, so the

speed can be controlled by changing the speed of the rotating magnetic field (power supply frequency). In addition, high operating efficiency is one of the advantages of the synchronous motor.

#### • Why is electrical angle measurement necessary?

In the case of a synchronous motor, a phase shifting occurs between the stator magnetic pole and the rotator magnetic pole due to a change in the load torque. This shifted angle and the torque force that can be generated by a motor have a close relationship, so it is important to understand this shifted angle (electrical angle) in order to achieve high-efficiency motor control.

#### • The 3390 provides a more accurate measurement method

The 3390 supports the incremental encoder output in addition to the measurement methods of the HIOKI 3194 Power HiTESTER – enabling you to measure this electrical angle more easily and accurately.

# 2 Perform harmonic analysis from the low-speed rotation range of motors


• Harmonic analysis from a synchronization frequency of 0.5 Hz Accurate measurements can be performed in the low-speed rotation range of motors without the need of an external clock.

If the synchronization frequency is 45 Hz or more, analysis results are updated every 50 ms, so data analysis can be performed in real time.

Synchronization frequency range	Window wave number	Analysis order
0.5Hz to 40Hz	1	100th order
40Hz to 80Hz	1	100th order
80Hz to 160Hz	2	80th order
160Hz to 320Hz	4	40th order
320Hz to 640Hz	8	20th order
640Hz to 1.2kHz	16	10th order
1.2kHz to 2.5kHz	32	5th order
2.5kHz to 5.0kHz	64	3rd order

# 3 Vector display of electrical angles of motors


• Display vectors including that of the phase angle and electrical angle ( $\varDelta\theta$ ) of fundamental wave voltage and current. The measured data can be used as parameters to calculate the Ld and Lq values.



# 5 X-Y graph display lets you check the dynamic characteristics of inverters

• X-Y graph display function built-in (X-axis: 1 item, Y-axis: 2 items)

By simply setting 2 items to the Y-axis as with a 6-axis graph used to evaluate motors, you can display the characteristics of a motor and similar devices in real time.



#### · Analyze up to the 100th order

Synchronized to the fundamental wave frequency of 0.5 Hz to 5 kHz Simultaneously perform analysis up to the 100th order harmonic along with power measurement



# 4 Clearly view the inverter efficiency/loss and motor power

• Output, efficiency, and loss of inverter motors can be measured with one single unit

Operating efficiency and power loss of the inverter and motor can be displayed when the inputs and outputs of the inverter are measured simultaneously.



# 6 Temperature data that is indispensable for motor evaluation can also be measured simultaneously

 Connect the HIOKI 3440 Series Temperature HiTESTER to measure changes in the motor temperature and acquire data as parameters for motor evaluation


Connect the HIOKI **3440** Series Temperature HiTESTER to the **3390** (via the RS-232C interface) to acquire data while displaying the temperature.



## ■ Application 2: Electrical angle measurement using induced voltage of motors (The same measurements conducted with the HIOKI 3194 can also be performed)

Correct the rotation synchronization signal and induced voltage phase of motors as well as measure the phase of voltage and current for the induced voltage of a running motor as an electrical angle.

Step 1: Turn the motor from the load side, and measure the induced voltage of the motor




- Measure the fundamental wave's RMS value and the total RMS value of the induced voltage.
- Perform zero compensation for the phase between the rotation synchronization signal and the fundamental wave voltage of the induced voltage.

#### Other Advance Functionsmotor

- Frequency divider circuit (up to 1/60000 frequency dividing) helpful when the rotation synchronization signal consists of multiple pulses for one cycle of induced voltage.
- \( \Delta\)-to-Y conversation function convert the line voltage to a phase voltage (virtual neutral reference) when
  three-phase three-wire (3P3W3M connection) measurements are performed.

#### Step 2: Measurement of a running motor



- Measure the fundamental wave component, harmonic component, and electrical angle of line voltage and current of a line to the motor. (The measured data can also be used as parameters for calculation of LplLq)
- Simultaneously measure motor efficiency, inverter efficiency, total efficiency, and inverter loss while observing the motor control.

# Evaluate new energies such as solar power, wind power, and fuel cells


Assess power conditioners that are indispensable for converting new energies to electrical power

#### **Advantages**

- 1. The input and output characteristics of a power conditioner can be measured simultaneously in combination with an AC/DC current sensor
- 2. Use of a current sensor makes the connection simple. Furthermore, accurate measurements can be performed in combination with the AC/DC CURRENT SENSOR 9709
- 3. The sale and purchase of electrical energy of a power line connected to a power conditioner can also be measured with one unit

#### Proprietary HIOKI Technology

- 4. Measure DC mode integration, which responds quickly to changes in the input of sunlight and the like, and RMS mode integration, which handles the separate integration of the sale and purchase of electric energy, all at the same time
- 5. Ripple factor, efficiency and loss, which are required to evaluate power conditioners for solar power generation, can be measured with one single unit.



# Conditioner-specific measurement items all measurable

 Power conditioner measurement-specific ripple factor and disequilibrium factor can also be measured and displayed simultaneously (up to 32 items can be displayed simultaneously), resulting in enhanced test efficiency

37.	,	
Display item	Measurement item	
rms value	RMS (DC/AC voltage/current of input and output)	
P, Q, S, λ values	Active power, reactive power, apparent power, power factor	
Loss value	Input and output loss	
η value	Efficiency	
thd value	Distortion factor (voltage/current)	
rf value	Ripple factor (for DC)	
unb value	Disequilibrium	
f value	Output frequency	



### ■ Current trends in solar power generation

Interconnected system of solar power generation and power conditioner

Electrical energy generated from the solar power generation is DC electrical energy, so it needs to be converted to AC electrical energy to be used by connecting to the utility grid. The device to convert direct current to alternating current is the power conditioner. In particular, to sell electrical energy by connecting to the utility grid, the performance of the power conditioner is important, so the method to evaluate the performance is specified by the national standards.

#### IEC standard


IEC 61683:1999, Photovoltaic systems -Power conditioners- Procedure for measuring efficiency

Evaluation and measurement of power conditioners

The IEC standard stipulates detailed measurement items to evaluate the input and output characteristics of power conditioners such as harmonic level, ripple factor, voltage disequilibrium factor, and voltage/current waveform.


 The 3390 supports a long list of measurement items including the specific ones required.

The  $3390\ \text{can}$  measure ripple factor and evaluate and analyze through simultaneous measurements.



# The efficiency (loss) and the amount of electrical energy sold and purchased can be displayed clearly

• Not only the amount of electricity generated with solar cells and the efficiency (loss) of a conditioner but also the amount of electrical energy sold and purchased by connecting to the utility grid can be measured simultaneously with one single unit



# 4 Accurately measure harmonics that are important for connecting to the utility grid

• The harmonic component and distortion factor important for connecting a power conditioner to the utility grid can be measured simultaneously.


Synchronized to the fundamental frequency of 0.5 Hz to 5 kHz.

Analyze up to the 100th order of voltage, current, and voltage harmonic, and display the current direction



# 3 Check the input and output waveforms of a conditioner

• Simultaneously check the input and output waveforms of a conditioner at 500 kS/s The input and output waveforms required to evaluate power conditioners can be checked simultaneously with one unit.



# 5 Also measure the noise flow of a connected utility grid

• Noise measurement function (1-channel measurement: Performed simultaneously with power measurement and harmonic analysis)

Noise components at up to 100 kHz can be read while looking at the measured waveforms Frequency and voltage/current levels for the top 10 points can be displayed simultaneously.




# Bundled software dedicated to the 3390 (free download from the HIOKI website)

#### **♦** Features

- Connect the 3390 to a PC via LAN or USB for completely remote operation
- Save measured data to the PC in real time (interval saving is also available)
- Download data stored in the USB memory or CF card
- Connect up to four 3390 Power Analyzers using the free software for remote operation and simultaneous data collection

General s	pecifications
Delivery media	Download from the HIOKI website
Operating	Windows 2000, XP, or Vista (32-bit version) PC
environment	Pentium III 500 MHz or higher CPU, 128 MB or more RAM, and LAN or USB interface
	Java Runtime Environment (JRE) 1.5.0 or later required
Communication	Ethernet (TCP/IP), USB 1.1/2.0
method	For a USB connection, use the supplied dedicated driver (included with the software)
Number of simultaneously- connected units	4
<b>■</b> Functions	
Remote operation function	Key operation and screen display on a PC
Download function	Downloads data stored on the media (Files in the USB memory or CF card)
Display function	Displays instantaneously measured values of the 3390 on the PC monitor
	Numerical display: Basic measurement items
	Waveform display: Instantaneous waveform data
	Bar graph: Harmonic
	Vector: Fundamental wave vector
Measured value	Saves the specified instantaneous value data to the PC
save function	Selects the item to save from the numerical value display items in the display function
Interval save function	Saves instantaneous value data to the PC at the specified interval
CSV conversion function	Saves the displayed waveform data in CSV format to the PC
BMP save function	Saves the displayed waveform and graph data in image format to the PC or copy images to the clipboard
0 (	Sends the settings of the 3390 made on a PC to the 3390
Setting function	School the settings of the 3000 made on a 1 C to the 3000



■3390 Specifications
(Accuracy guarantee conditions: 23°C ±3°C, 80%RH or less, warm-up time 30 minutes or more, sinusoidal wave input, power factor 1, voltage to ground 0 V, in the range where the fundamental wave meets the conditions of the synchronization source after zero adjustment)

Input				<u> </u>
Measurement line	Single-phase two phase three-wire (	Single-phase two-wire (1P2W), single-phase three-wire (1P3W), three phase three-wire (3P3W2M, 3P3W3M), three-phase four-wire (3P4W)		
Connection setting	CH1 CH2		CH3	CH4
Pattern 1	1P2W	1P2W	1P2W	1P2W
Pattern 2	1P.	3W	1P2W	1P2W
Pattern 3	3P3V	W2M	1P2W	1P2W
Pattern 4	1P.	3W	1P.	3W
Pattern 5	3P3V		1P:	
Pattern 6	3P3V	W2M	3P3V	V2M
Pattern 7		3P3W3M		1P2W
Pattern 8		3P4W		1P2W
Number of input channels	Voltage: 4 channel Current: 4 channel			
Input terminals	Current: Dedicated			
Input method		nput, resistance vol nput using current s		
Measurement range	(Selectable for each	ch connection, auto	range available)	
Voltage range		/ 60.000V / 150.00V		
Current range		00mA / 2.0000A / 4.0		
( ) indicates the sensor rating used		/20.000A / 40.000A / / 5.0000A / 10.000A /		
sensor rating used	1.0000A / 2.0000A / 5.0000A / 10.000A / 20.000A / 50.000A (50 A rating) 10.000A / 20.000A / 50.000A / 100.00A / 200.00A / 500.00A (500 A rating) * Only UNIVERSAL CLAMP ON CT 9277 is applicable			
Power range	Depends on combin	nation of voltage and	current range (6.0000	W to 2.2500 MW)
Crest factor	3 (voltage/current), 1.33 for 1500 V			
Input method (50/60Hz)	Voltage input part: 2 M $\Omega$ ±40 k $\Omega$ (Differential input and isolated input) Current sensor input part: 1 M $\Omega$ ±50 k $\Omega$			
Maximum input voltage		: 1500 V ±2000 V p out part: 5 V ±10 V p		
Maximum rated voltage to ground	Voltage input terminal 1000 V (50/60 Hz) Measurement category III 600 V (Expected transient overvoltage 6000 V) Measurement category II 1000 V (Expected transient overvoltage 6000 V)			
Measurement method	Voltage and current simultaneous digital sampling and zero cross synchronization calculation method			
Sampling	500kHz / 16bit			
Frequency band	DC, 0.5 Hz to 150	) kHz		
Synchronization frequency range	0.5Hz to 5kHz			
Synchronization source	U1 to U4 / I1 to I4 / Ext (with motor analysis option, CH B: when pulse is set) / DC (50 ms, 100 ms fixed)  * Selectable for each connection (Zero cross auto follow-up by digital LPF when U / 1), Filter resistance two-stage switching (high / low), source input 30%f.s. or more when U / 1			
Data update rate	50ms			
LPF	OFF / 500 Hz / 5 kHz / 100 kHz (Selectable for each connection) When 500 Hz: Accuracy +0.1%f.s. specified at 60 Hz or less When 5 kHz: Accuracy specified at 500 Hz or less When 100 kHz: Accuracy specified at 20 kHz or less (1%rdg. is added at 10k Hz to 20 kHz)			
Polarity determination	-	ro cross timing con	-	
Polarity determination Measurement parameters	Voltage (U), current (I), active power (P), apparent power (S), reactive power (Q), power factor ( $\lambda$ ), phase angle ( $\phi$ ), frequency (f), efficiency ( $\eta$ ), loss (Loss) voltage ripple factor (Ufr), current ripple factor (Ifr), current integration (Ih) power integration (WP), voltage peak (Upk), current peak (Ipk)			

Accurate	Voltage, currency,	and active power m	easurements
Accuracy			
	Voltage (U)	Current (I)	Active power (P)
DC	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
0.5Hz to 30Hz	±0.1%rdg.±0.2%f.s.	±0.1%rdg.±0.2%f.s.	±0.1%rdg.±0.2%f.s.
30Hz to 45Hz	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
45Hz to 66Hz	±0.05%rdg.±0.05%f.s.	±0.05%rdg.±0.05%f.s.	±0.05%rdg.±0.05%f.s.
66Hz to 1kHz	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.	±0.1%rdg.±0.1%f.s.
1kHz to 10kHz	±0.2%rdg.±0.1%f.s.	±0.2%rdg.±0.1%f.s.	±0.2%rdg.±0.1%f.s.
10kHz to 50kHz	±0.3%rdg.±0.2%f.s.	±0.3%rdg.±0.2%f.s.	±0.4%rdg.±0.3%f.s.
50kHz to 100kHz	±1.0%rdg.±0.3%f.s.	±1.0%rdg.±0.3%f.s.	±1.5%rdg.±0.5%f.s.
100kHz to 150kHz	±20%f.s.	±20%f.s.	±20%f.s.
	* Voltage, currency, and active power values at 0.5 Hz to 10 Hz are reference values  * Voltage and active power values more than 220 V at 10 Hz to 16 Hz are reference values  * Voltage and active power values more than 750 V at 30 kHz to 100 kHz are reference values  * Voltage and active power values more than (22000F [kHz]) V at 100 kHz to 150 kHz are reference values  * Voltage and active power values more than 1000 V are reference values  * As for the current and active power values, add the accuracy of the current sensor to the above accuracy		
Accuracy guarantee period	6 months (One-year accuracy is the above accuracy x 1.5)		
Temperature coefficient	±0.01%.f.s/°C (When DC: Add ±0.01%f.s/°C)		
Effect of common mode voltage	$\pm 0.01\% f.s.$ or less (When applying 1000 V (50/60 Hz) between the voltage input terminal and the case)		
Effect of external magnetic field	±1.0%f.s. or less (in a magnetic field at 400 A/m, DC, and 50/60 Hz)		

Effect of power	$\pm 0.15\%$ f.s. or less (When power factor = 0.0 at 45 Hz to 66 Hz), add	
factor	±0.45% f.s. when LPF is 500 Hz	
Iacioi	±0.45 /01.5. WHOH ETT 15 500 TIZ	
Effective		
	Voltage, current, and power: 1% to 110% of range	
measurement range		
Display range	Voltage, current, and power: Range's zero suppress range setting to ±120%	
Zero suppress	Selects from OFF, 0.1%f.s., and 0.5%f.s.	
Zeio suppiess		
range	* When OFF is selected, a numerical value may be displayed even if zero is input	
	Voltage: ±10%f.s.	
Zero adjustment	Current: ±10%f.s. zero correction is performed for an input offset less than ±4 mV	
	Current. ±10 %1.5. Zero correction is performed for all hiput offset less than ±4 hrv	
Waveform peak	Range: Within ±300% of respective voltage and current range	
measurement	Accuracy: Voltage and current respective display accuracy ±2%f.s.	
measurement	recurred. Voltage and earliest respective display accuracy ±2 %1.5.	

Frequency n	neasurement
Number of measurement channels	4 channels (f1, f2, f3, f4)
Measurement source	Selects from U / I for each input channel
Measurement method	Reciprocal method + zero cross sampling value correction
Measurement range	Within synchronization frequency range between 0.5 Hz and 5 kHz
Data update rate	50 ms (Depends on the frequency when 45 Hz or less )
Accuracy	±0.05%rdg.±1dgt. (When sinusoidal waveform is 30% or more relative to the measurement range of measurement source)
Display range	0.5000Hz to 9.9999Hz / 9.900Hz to 99.999Hz / 99.00Hz to 999.99Hz / 0.9900kHz to 5.0000kHz

Integration r	Integration measurement		
Measurement mode	RMS / DC (Selectable for each connection, DC is only available when AC/DC sensor is used for 1P2W connections) RMS: Integrates the current RMS values and active power values, only the active values are integrated for each polarity DC: Integrates the current values and instantaneous power values for each polarity		
Measurement item	Current integration (Ih+, Ih-, Ih), active power integration (WP+, WP-, WP) Ih+ and Ih- are available only in DC mode, and only Ih is available in RMS mode.		
Measurement method	Digital calculation from each current and active power		
Measurement interval	Data update rate of 50 ms		
Display resolution	999999 (6 digits + decimal point)		
Measurement range	0 to ±9999.99 TAh / TWh (Integration time is within 9999 h 59 m)  If any integration value or integration time exceeds the above limit, integration stops.		
Integration time accuracy	±50 ppm ±1 dgt. (0°C to 40°C)		
Integration accuracy	±(Accuracy of current and active power) ± integration time accuracy		
Backup function	If power fails during integration, integration resumes after power is restored		

Harmonic measurement			
Integration time accuracy	4 channels (Harmonic measurement for another line at a different frequency cannot be performed)		
Measurement item	Harmonic voltage RMS value, harmonic voltage percentage, harmonic voltage phase angle, harmonic current RMS value, harmonic current percentage, harmonic current phase angle, harmonic active power, harmonic power percentage, harmonic voltage/current phase difference, total harmonic voltage distortion factor, total harmonic current distortion factor, voltage disequilibrium factor, current disequilibrium factor		
Measurement method	Zero cross synchronous cal	culation method (All chann	nels same window) with gap
Synchronization source	U1 to U4 / I1 to I4 / Ext (Motor analysis option included, CHB: when pulse is set) / DC (50 ms/100 ms)		
FFT processing word length	32-bit		
Anti-aliasing filter	Digital filter (Variable by the synchronization frequency)		
Window function	Rectangular		
Synchronization frequency range	0.5 Hz to 5 kHz		
Data update rate	50 ms (Depends on the sy	ynchronization frequency	when less than 45 Hz)
Phase zero adjustment	Phase zero adjustment is possible by key / communication command (only when the synchronization source is Ext)		
	Synchronization frequency range	Window wave number	Analysis order
	0.5Hz to 40Hz	1	100th order
	40Hz to 80Hz	1	100th order
	80Hz to 160Hz	2	80th order
Maximum analysis order	160Hz to 320Hz	4	40th order
	320Hz to 640Hz	8	20th order
	640Hz to 1.2kHz	16	10th order
	1.2kHz to 2.5kHz	32	5th order
	2.5kHz to 5.0kHz	64	3rd order

	Frequency	Voltage (U) / current (I) / active power(P)	
	0.5Hz to 30Hz	±0.4%rdg.±0.2%f.s.	
	30Hz to 400Hz	±0.3%rdg.±0.1%f.s.	
Accuracy	400Hz to 1kHz	±0.4%rdg.±0.2%f.s.	
ricouracy	1kHz to 5kHz	±1.0%rdg.±0.5%f.s.	
	5kHz to 10kHz	±2.0%rdg.±1.0%f.s.	
	10kHz to 13kHz	±5.0%rdg.±1.0%f.s. en the synchronization frequency is 4.3 kHz or more	
Noise meas	urement (FFT proces		
	1 channel (Selects one chann	<i></i>	
Measurement item	Voltage/current		
Calculation type Measurement	RMS spectrum		
method	500 kHz/s sampling (Decima	ation after digital anti-aliasing filtering)	
FFT processing word length	32-bit		
Number of FFT	1.000 points / 5.000 points	/ 10,000 points / 50,000 points (Linked to the	
points	waveform display record len	gth)	
		y the maximum analysis frequency)	
Window function	Rectangular / Hanning / flat t	•	
Data update rate Maximum analysis		epending on the number of FFT points, with gap	
frequency	100kHz / 50kHz / 20kHz / 10		
Frequency resolution	0.2 Hz to 500 Hz (Determ	tined by the number of FFT points and the	
Noise value	, , ,	frequencies of voltage and current peaks	
measurement	(maximum values) for the to		
MOTOR TES	TING OPTION (Ann	icable to the 9791 and 9793)	
moron rec	3 channels	ioabie to the erer and erec)	
Number of input	CH A: Analog DC input / frequency input (torque signal input)		
channels	CH B: Analog DC input / pulse input (rotation signal input) CH Z: Pulse input (Z-phase signal input)		
Input terminal form	Isolation type BNC connector		
Input resistance (DC)	1 M Ω ±100 kΩ		
Input method		l input (No isolation between CH B and CH Z)	
Measurement item	Voltage, torque, rotation, free	quency, slip, motor output	
Maximum input voltage	±20 V (When analog / freque	ency / pulse)	
Maximum rated voltage to ground		ement category I 50 V (Expected transien	
Accuracy	,	y is the accuracy below x 1.5)	
guarantee period		is the accuracy below x 1.3)	
1. Analog DC in Measurement range	put (CH A / CH B) ±1 V / ±5 V / ±10 V (When a	malas DC input)	
Effective input range		malog DC input )	
Sampling	10 kHz / 16-bit		
Measurement		ng and zero cross synchronization calculation	
method Synchronization	method (zero cross averaging	g) surement input specification (Common for CH A	
source	and CH B)	sarement input specification (Collinion for CH A	
Accuracy	±0.1%rdg. ±0.1%f.s.		
Temperature coefficient	±0.03%f.s./°C		
Effect of common		olying 50 V (DC 50/60 Hz) between the input	
mode voltage	terminal and the 3390 case		
Display range Zero adjustment	Range's zero suppress range	setting to ±120%	
2. Frequency in	Voltage ±10%f.s.		
Effective			
amplitude range	±5Vpeak		
Measurement range			
Band width Accuracy	1kHz to 100kHz ±0.05%rdg,±3dgt.		
Display range	1.000kHz to 99.999kHz		
3. Pulse input (c			
Detection level	Low: 0.5 V or less, High: 2.0		
Measurement band	1 Hz to 200 kHz (When duty	ratio is 50%)	
Frequency divider			
setting range	1 to 60000		
setting range Measurement	0.5 Hz to 5.0 kHz (Specifie		
setting range		d by the frequency at which the measurement equency dividing number)	

detection width

Minimum detection width Setting

Number of output channels

 $2.5\ \mu s$  or more

16 channels

Measurement band 0.1 Hz to 1 kHz

Accuracy ±0.05%rdg. ±3dgt.

4. Pulse input (only for CH Z)

Detection level Low: 0.5 V or less, High: 2.0 V or more

OFF / ON (When ON, a frequency divider circuit of CH B is cleared by a rising edge)

D/A OUTPUT OPTION (Applicable to the 9792 and 9793)

Outrat sentent	Switchable between Waveform output / Analog output (selects from the	
Output content	measurement items) * Waveform output is only for CH 1 to CH 8	
Output terminal form	D-sub 25-pin connector x 1	
D/A conversion resolution	16-bit (Polarity + 15-bit)	
Output voltage	Analog: DC ±5 Vf.s. (Max. about DC ±12V) Waveform output: 2 Vrms f.s., crest factor: 2.5 or more	
Accuracy	Analog output: Measurement accuracy $\pm 0.2\%$ f.s. (DC level) Waveform output: Measurement accuracy $\pm 0.5\%$ f.s. (at RMS level, in synchronization frequency range)	
Accuracy guarantee period	6 months (one-year accuracy is the above accuracy $\times$ 1.5)	
Output update rate	Analog output: 50 ms (As per the data update rate of the selected item) Waveform output: 500 kHz	
Output resistance	100 Ω ±5 Ω	
Temperature coefficient	±0.05%f.s./°C	
Display		
Display character	English / Japanese / Chinese (simplified characters)	
Display	9-inch TFT color LCD display (800 × 480 pixels)	
LCD backlight	ON / Auto OFF (1min / 5min / 10min / 30mim / 60min)	
Display resolution	99999 counts (Integrated value: 999999 counts)	
Display refresh rate	200 ms (Independent of internal data update rate; waveform and FF7 depend on the screen)	
Display screen	Measurement, Setting, File Manipulation screens	
External inte	erfaces	
1. USB Interface		
Connector	Series Mini-B receptacle	
Electrical specification Number of ports	USB2.0 (Full Speed / High Speed)	
Class	Vendor specific (USB488h)	
Destination	PC (Windows 2000 / XP / Vista (32-bit version))	
Function	Data transfer, remote operation, command control	
2. USB memory	interface	
Connector	USB type A connector	
Electrical specification	USB2.0	
Power supply	Up to 500 mA	
Number of ports	1	
Applicable USB memory	USB Mass Storage Class	
Recordable items	Setting file: Save/Load Measured value/recorded data: Copy (from the CF card data) Waveform data: Save, screen hard copy	
3. LAN interface		
Connector	RJ-45 connector × 1	
Electrical specification	IEEE802.3 compliant	
Transmission method	10BASE-T / 100BASE-TX auto recognition	
Protocol	TCP/IP	
Function	HTTP server (remote operation), dedicated port (port transfer, command control)	
4. CF card interf	ace TYPE I × 1	
Usable card	Compact flash memory card (32 MB or more)	
Applicable	•	
memory capacity	Up to 2 GB	
Data format	MS-DOS format (FAT16 / FAT32)	
Recordable	Setting file: Save / Load	
items	Measured value / automatically recorded data: Save (in CSV format) Waveform data: Save, screen hard copy	
5. RS-232C inter Method	RS-232C, EIA RS-232D, CCITT V.24, JIS X5101 compliant	
Connector	D-sub 9-pin connector × 1	
Destination	Printer / thermometer	
Recordable	Full duplex asynchronous method Data length: 8, parity: none, stop bit: 1,	
items	Flow control: Hard flow, delimiter: CR+LF	
Baud rate	2400, 9600, 19200, 38400 bps (2400 bps for thermometer)	
	ion control interface	
Terminal form Signal	IN-side 9-pin round connector x 1, OUT-side 8-pin round connector x 1  5 V (CMOS level)	
	,	
Maximum	1 ±20V	
allowable input	±20V	

Functions	
1. Setting	
Rectification switching	rms / mean (Selectable for the voltage/current of each connection) rms: Displays the true RMS value (True RMS) mean: Displays the average-value rectified RMS value
Auto range	OFF / ON (Voltage and current range is selectable for each connection)

Up to 2 μs (Specified by the rising edge)

Signal delay

	OEE / 50 /	100 ms / 200 ms	/500 / 1 . /	F - / 10 - / 15	- / 20 - /	Motor coroon	Disclared to the second of the MOTOR TESTING OPTION 0704 (0702)		
		100 ms / 200 ms / 10 min / 15 mir			S / 30 S /	Motor screen	Displays the measured values of the MOTOR TESTING OPTION 9791 (9793).  Display pattern: Displays the numerical values of 4 items		
		mber of items to s	ave can be specif	ied by the setti	ng (130 items/50	3. Data save			
	ms, up to 5000 i	tems)				Auto data save	Saves each measured value to the CF card at each interval		
	Interval time and maximum number Guide to the time during which items can be of Items to be saved saved automatically(When using a 512 MB card)					Save destination	OFF / CF card (cannot be saved to the USB memory), the save destination folder can be specified		
Data save interval	Interval	Number of ite	Number of items	s to be saved   Time during	which items can be stored	Save itemAuto	Any item can be selected from all measured data, including harmonic value, and peak value of the noise measurement function		
interval	50ms	130 (When 200 ms:	520)		out 2 days ut 14 hours	Data format	CSV file format		
		2600	10		out 42 days		Saves each measured value to each save destination when the SAVE key is pressed		
	1s	(5 s or more: 50			ut 11 hours	Save destination	<u> </u>		
	1 min	5000	40	Abo	ut 416 days	Save itemSave	Any item can be selected from all measured data, including harmonic value, and peak value of the noise measurement function		
	1min	5000	400	0 Ab	out 7 days	Data format	-		
Time central	OFF / Timer /		0.1, 50 50 - (-			Screen hard copy Save destination	Saves the display screen to the save destination when the COPY key is pressed USB memory / CF card / printer		
Time control		mer: 10 s to 999 ctual Time: Start					* The save destination folder can be specified when USB memory or CF card is specified.		
Scaling		/ 0.01 to 9999.99				Data format Setting data save	Compressed BMP format (256 colors), monochrome when printer is selected  Setting information can be saved and loaded to and from the save		
Averaging		eraged values of		sly measured v	values including	Setting data save	destination as a setting file		
	harmonic value	:		•		Save destination	(With the exception of language setting and communication setting) USB memory / CF card (the save destination folder can be specified)		
		peak value, integ a applies to all da			ring averaging		nected equipment		
Method	Exponential av	eraging (Applie	s to the data upo	late rate of 50	ms)	Synchronized	The <b>3390</b> master and <b>3390</b> slaves can be connected with synchronization		
Response time		ST) / 1.0s (MID			000 . 10000 .	measurement	cables to perform synchronized measurements		
Efficiency/loss	`	th to fall in the accur e efficiency $\eta$ [9	, ,	1 0			* If the interval setting is identical, synchronized measurements can be saved automatically		
calculation	connection and		oj una 1000 [ vi	j or dealer p		Synchronized item	1 1 1		
Calculated item		ralue (P) for each m) when the 9791			n ie included	Event item	data reset, event  Hold, manual save, screen copy		
Calculation rate		updates at a data			1 IS IIICIUUCU	Synchronization timing			
ou.ou.u.oruto	* The latest	data of calcula	ation is used	for a calcula	ation between	Oynomonization timing	master by the key or via communication)		
Oala lakia taataa		hose synchroniza				Synchronization delay			
Calculable factors Calculation algorithm		ne efficiency and l n is specified for			elow.	Temperature measurement Applicable thermometer	Acquires the measured temperature values from the thermometer connected to the RS-232C interface		
Calculation algorithm		/  Pin  , Loss=		tuic format oc	ZIOW	Number of channels			
		voltage wavefe		oltage wavef	form using the		1 channel		
Δ – Y calculation		point for 3P3W3 oltage to calcula		rameters incl	uding harmonic	Printer output	Screen copy is printed to the printer connected to the RS-232C interface		
	or voltage RM		ne un voltage pe	arameters men	ading narmonic	Applicable printer Output content	HIOKI 9670 Screen hard copy		
Display hold		ys all displayed me				Printer setup	Printer auto setup function available		
Data update		when the hold hen an external				5. System			
Output data		data save: Output	-			Display language	English / Japanese / Chinese* (*available soon)		
·	and the interval	auto-save outputs	data immediately	before it is upda	nted)	Clock function	Auto Calendar, Auto Leap Year Adjustment, 24 Hour Meter		
Peak hold	1 2	odates the maximo ay and integrated		h of all measur	red data (without	Clock setting Real time accuracy			
		ng is performed,		lue is applied	to the measured	Beep tone	OFF / ON		
Data undata		aging. This cannot				Screen color	COLOR1 / COLOR2 / COLOR3 / COLOR4 / MONO		
Data upuate		d when the hole when an external					Connection screen / screen closed in the previous session (Measurement screen only)		
0 1 1 1 1 1	updated at an	nternal data upd	ate rate of 50 m	s)		LCD backlight Sensor recognition	ON / 1min / 5min / 10min / 30min / 60min Automatically recognizes the current sensor connected		
Output data	Diri output, Ci	data save: Outputs n output contin			ua autoute data	Alarm display	Voltage/current peak over threshold detection, synchronization source non-		
		efore it is cleared		civai auto-sa	ve outputs data		detection (Alarm mark on)		
2. Display						Key lock	ESC key: ON/OFF by holding down the key for 3 seconds (Key lock mark on)		
Connection check screen	Displays the connection diagram and the voltage/current vector diagram  * The right connection range is displayed in the vector diagram, so the connection can be checked.					System reset	Sets the equipment to the default (factory) settings (Communication settings are not changed)		
Connection	-	ured power and l				File manipulation	5 7		
display screen		displayed for each n					deletion, file copy between media		
DMM screen		rement screen screen, Power M			reen, Current	Canavalana	oifications		
Harmonic screen		en, List screen, Ve				General spe	Indoors, altitude up to 2000 m, contamination class 2		
Select/Display		splays any 4, 8,	16, or 32 meas	urement items	from all basic	Storage temperature	, <u> </u>		
screen	measurement i	tems n: 4 items, 8 item	ns, 16 items. or	32 items (4 nat	ttern switching)	and humidity ranges	-10°C to 50°C, 80%RH or less (No dew condensation)		
Efficiency/Loss	Displays the nu	merical values of	efficient and loss			Operating temperature and humidity ranges	0°C to 40°C, 80%RH or less (No dew condensation)		
screen Waveform & Noise		3 efficiency item tage/current wavef		500 kHz in a co-	mnracead caroon		For 15 seconds at 50/60 Hz		
Measurement screen		aveform and noise					AC5.312 kVrms: Between the voltage input terminal and the unit case		
	measurement is	performed				Withstand voltage	AC3.32 kVrms: Between the voltage input terminal and the current input terminal / interface		
Trigger Record Length		on timing of harm 000 points / 10,000			a/ourrant observal-	Thuistand Voltage	AC370 Vrms: Between the <b>9791</b> and <b>9793</b> input terminals (CH A, CH B,		
Compression Ratio		/10, 1/25, 1/50 (1			Sourcest Challets		CH Z) and the unit case		
Recording time	Recording speed /		1	· · · · · · · · · · · · · · · · · · ·			Between CH A and CH B / CH Z		
	Recording length		5,000 points	•		Applicable standard	Safety: EN61010-1 EMC: EN61326-1 Class A, EN61000-3-2, EN61000-3-3		
	500kS/s	2ms	10ms	20ms	100ms	Rated power	100 to 240 VAC (expected transient overvoltage of 2500 V), 50/60 Hz		
	250kS/s	4ms	20ms	40ms	200ms 500ms	supply voltage			
	100kS/s 50kS/s	10ms 20ms	50ms 100ms	100ms 200ms	1000ms	Maximum rated power Dimensions	140VA 340 (W) × 170 (H) ×157 (D) mm (excluding protrusions)		
	25kS/s	40ms	200ms	400ms	2000ms	Weight	4.8 kg (including the <b>9793</b> )		
	10kS/s	100ms	500ms	1000ms	5000ms		About 10 years (a reference value of a lithium ion battery used at 23°C to		
X-Y Plot screen	Selects items or	the horizontal an	d vertical axes fro	om the basic me	easurement items	Drodust warest and a	back up the clock, setting conditions, and integrated values)		
	and displays the	m in the X-Y grapl	h			Product warranty period	1 year		
Ontion		wn at the data update s: 1 item (with g		corded, and draw	ing data is cleared				
Οριίοι		items (with gau							
			_ 1 2/						

Basic calc	ulation alg	orithms						
Connection	1P2W	1P3W	3P3W2M	3P3W3M	3P4W			
Voltage and current RMS value (True RMS value)		$\frac{1}{2} \left( Xrms_{(i)} - \frac{1}{2} \right)$		$Xrms123 = \frac{1}{3}(Xrms_1 + Xrms_2 + Xrms_3 + Xrms_4 + Xrms_5 + Xrms_5 + Xrms_6 + X$				
Voltage and current average rectified RMS indication value	Xmn(i)=	Xmn12 or Xn	nn34 =	Xmn123 =	$\frac{\text{Xmn123} = \frac{1}{3}(\text{Xmn}_1 + \text{Xmn}_2 + \text{Xmn}_3)}{\frac{1}{3}(\text{Xmn}_1 + \text{Xmn}_2 + \text{Xmn}_3)}$			
Voltage and current alternating-current component	1, ,2 , ,2							
Voltage and current mean value	$Xdc(i) = \frac{1}{M} \sum_{i=0}^{M-1} X_{i(i)}$							
Voltage and current fundamental wave component	Fundamental wave value X1(i) based on the harmonic calculation result							
Voltage and current peak value	Maximum value among X pk+(i) = X (i)s M Minimum value among X pk-(i) = X (i)s M							
Active power	$\begin{split} P(i) &= \\ \frac{1}{M} \sum_{s=0}^{M-1} \bigl( U_{(i)s} \times I_{(i)s} \bigr) \end{split}$	P12 = P34 =	P123 =P	1+P2+P3				
	<ul> <li>In the cases of 3PWW3M and 3P4W connections, phase voltage is used for the voltage waveform U (i)s.</li> <li>(3PW3M: U1s = (U1s-U3s)3, U2s = (U2s-U1s)3, U3s = (U3s-U2s)42s)3)</li> <li>The polarity symbols of active power P indicate the power direction when power is consumed (+P) and when power is regenerated (+P)</li> </ul>							
Apparent power	$S(i) = U(i) \times I(i)$	S12 =S1+S2 S34 =S3+S4	$S_{12} = \frac{\sqrt{3}}{2} (S_1 + S_2)$ $S_{34} = \frac{\sqrt{3}}{2} (S_3 + S_4)$	S123 =S	1+S2+S3			
	Selects rms or mn for U(i) and I(i)     In the cases of 3P3W3M and 3P4W connections, phase voltage is used for the voltage U (i)							
	$\begin{array}{c} Q(i) = \\ si_{(i)} \sqrt{{S_{(i)}}^2 - {P_{(i)}}^2} \end{array}$		Q1+Q2 Q3+Q2	Q123 =Q	1+Q2+Q3			
Reactive power	•The polarity symbol si of reactive power Q indicates symbol [none]: lag and symbol [-]: lead. •The polarity symbol si(i) is determined by lag or lead of voltage waveform U (i)s and current waveform I (i)s for each measurement channel (i), and in the cases of 3P3W3M and 3P4W connections, phase voltage is used for the voltage waveform U (i)s.							
Power factor	$\lambda(i) = \frac{si_{(i)}}{si_{(i)}} \frac{P_{(i)}}{S_{(i)}}$	$\lambda_{12} = \sin_2 \left  \frac{P_{12}}{S_{12}} \right $	$\lambda_{34} = si_{34} \frac{P_{34}}{S_{34}}$	$\lambda_{123} = \sin$	$\frac{P_{123}}{S_{123}}$			
	<ul> <li>The polarity symbol si of power factor \( \hat{\}\) indicates symbol [none]: lag and symbol [-]: lead.</li> <li>The polarity symbol si(i) is determined by lead or lag of voltage waveform U (i)s and current waveform I (i)s for each measurement channel (i), and si 12, si34, and si 123 are determined by the symbol of Q12, Q34, and Q123, respectively.</li> </ul>							
Phase angle	$ \phi(i) = \\ si_{(i)}cos^{-1} \left  \lambda_{(i)} \right  $	$\phi_{12} = \sin_{2} \alpha$ $\phi_{34} = \sin_{3} \alpha$	$\cos^{-1} \lambda_{12} $ $\cos^{-1} \lambda_{34} $	$\phi_{123} = si_{123}$	$\cos^{-1}  \lambda_{123} $			
	The polarity symbol si(i) is determined by lead or lag of voltage waveform U (i)s and current waveform I (i)s for each measurement channel. si12, si34, and si123 are determined by the symbol of Q12, Q34, and Q123, respectively.							
(i): Measurement channel, M: Number of samples between synchronization timings, s: Sample point number								

Motor analysis calculation algorithm						
Item	Setting unit	Calculation algorithm				
	V (DV voltage)	$\frac{1}{M}\sum_{s=0}^{M-1} A_s$				
chA	N• m / mN• m / kN• m	When analog DC	A [V] × chA scaling setpoint			
0	common (torque)	When frequency	(Measurement frequency - fc setpoint) × rated torque setpoint / fd setpoint			
	M: Number of samp	M: Number of samples between synchronization timings, s: Sample point number				
	V (DC voltage)	$\frac{1}{M}\sum_{s=0}^{M-1}B_s$				
	Hz (frequency)	When analog DC	B[V] × chB scaling setpoint			
chB		When pulse input	Pole number setpoint x pulse frequency / 2 × pulse number setpoint			
	r/min (rotation)	When analog DC	B[V] × chB scaling setpoint			
		When pulse input	$2 \times 60 \times$ frequency [Hz] / pole number setpoint			
	N• m (unit of chA)	(Indicated value of chA) $\times$ 2 $\times$ $\pi$ $\times$ (indicated value of chB) / 60				
	mN• m (unit of chA)	(Indicated value of chA) $\times 2 \times \pi \times$ (indicated value of chB) / 60 / 1000				
Pm	kN• m (unit of chA)	nit of chA) (Indicated value of chA) $\times 2 \times \pi \times$ (indicated value of chB) $\times 1000 / 60$				
	Calculation cannot be performed when the unit of chA is other than the above, or the unit of chB is other than r/min.					
	Hz (unit of chB)	100 × input frequency – indicated value of chB / input frequency				
Slip	r/min (unit of chB) $100 \times 2 \times 60 \times \text{input frequency} - \text{indicated value of chB} \times \text{pnumber setpoint} / 2 \times \pi \times \text{input frequency}$					
	Selects the input frequency from f1 to f4					

When using the **3390** with a DC power supply as with the case of on-vehicle measurements: Provide a DC-AC converter separately.

Required DC-AC converter output specification
Output type : Sinusoid wave type, 50/60 Hz (60 Hz recommended)
Output capacity: The maximum power consumption of the **3390** is
140VA. Select a rating more than the capacity.

## ■ Options

#### Options for current measurements

CLAMP ON SENSOR 9272-10 (AC) UNIVERSAL CLAMP ON CT 9277 (AC/DC) UNIVERSAL CLAMP ON CT 9278 (AC/DC)

UNIVERSAL CLAMP ON CT 9279 (AC/DC) AC/DC CURRENT SENSOR 9709 (AC/DC)

Overview of sensor specifications (Accuracy guarantee period of 1 year with the exception of the **9709** for 6 months)

Model 9272-10		9277	9278	9279	9709		
	<b>%</b>			100			
	CAT III 600V	CAT II 600V CAT III 300V	CAT II 600V CAT III 300V	Not CE-marked 600 V insulated conductor	CAT III 1000V		
Rated current	AC 20A/200A	AC/DC 20A	AC/DC 200A	AC/DC 500A	AC/DC 500A		
Maximum continuous input range	50A/300A rms	50A rms	350A rms	650A rms	700A rms		
Accuracy (45 to 66 Hz, DC: DC compatible sensor)	±0.3%rdg.±0.01%f.s., ±0.2°	(30 minutes a	±0.5%rdg.±0.059 ±0.2° after power is turned on a	,	±0.05 %rdg.±0.01 % f.s. , ±0.2° (10 minutes after power is turned on)		
Frequency characteristic	1Hz to 5Hz: ±2%rdg.±0.1%f.s. 1kHz to 5kHz: ±1%rdg.±0.05%f.s. (±1.0) 10kHz to 50kHz: ±5%rdg.±0.1%f.s.		DC to 1kHz: ±1.0% ±2.5 % (±2.5°) : ±5.0 % (±5.0°)	( ±0.5°) 1 k to 10 kHz: ±2.5 % (±2.5°) 10 k to 20 kHz: ±5.0 % (±5.0°)	DC to 45Hz: ±0.2%rdg.±0.02%f.s.(±0.3°) 5kHz to 10kHz: ±2%rdg.±0.1%f.s. (±2.0°) 20kHz to 100kHz: ±30%rdg.±0.1%f.s. (±30°)		
Measurable conductor diameter	ф 46mm	ф 20	mm	ф 40mm	ф 36mm		
Dimensions/ weight	78W×188H×35Dmm, 850g	176W×69H×2	7Dmm, 470g	220W×103H×43.5Dmm, 860g	160W×112H×50Dmm, 850g		
	Cord length: 3 m						

#### Options for voltage measurements

Voltage Cord 9438-50 (Red x1 and black x 1, 600 V specification) Voltage Cord 9438-70 (Red x 1 and black x 1, 1000 V specification) Grabber Clip 9243 (Red x 1 and black x 1)



CAT III 600V

9438-50

Usage:

Indoor wiring in buildings and factories for measurements up to



Cord length: 3 m

Usage:

Indoor wiring in buildings and factories for measurements up to 600 V; can also be used for internal voltage measurements of equipment up to 1000 V.



Usage:

Attaches to the end of the Voltage Cord 9438-50 or 9438-70.



PC Card 256M 9727 (Capacity: 256 MB) PC Card 512M 9728 (Capacity: 512 MB) PC Card 1G 9729 (Capacity: 1 GB)

PC connection and other options

LAN CABLE 9642

CONNECTION CORD 9217 (For input of the 9791 and 9793 with a length of 1.5 m) CONNECTION CABLE 9683 (For synchronized measurement with a length of 1.5 m)

CARRYING CASE 9794 (Hard case dedicated to the 3390)

Rack mount brackets



Use only PC Cards sold by HIOKI Compatibility and performance are not guaranteed for PC cards

made by other manufacturers. You

may be unable to read from or save

data to such cards







Ready for truck, air, or other

Hard trunk to protect your 3390 during transportation (With casters)

#### **Printer option**

PRINTER 9670

AC ADAPTER 9671 (For the Printer 9670, AC 100 V to 240 V) RS-232C CABLE 9638 (To connect the 9670, 1.8 m (5.91 ft) length) RECORDING PAPER 9237 (80 mm×25 m, 4 rolls)





When purchasing the PRINTER 9670, please also purchase the AC ADAPTET

9671. To connect to the 3390, please purchase the RS-232C CABLE 9638.





For display copy, includes 1 roll of recording paper, Power supply AC Adapter 9671

■ Factory options (please specify at the time of order)

9217

**MOTOR TESTING OPTION 9791** D/A OUTPUT OPTION 9792 MOTOR TESTING & D/A OUTPUT OPTION 9793

## **Ordering Information**

#### **POWER ANALYZER 3390**

Accessories: Instruction Manual × 1, Measurement Guide × 1, Power cord × 1, USB cable × 1, D-sub connector × 1 (when 9792 or 9793 is installed), Color label × 2

Note: Dedicated PC application software and communication command manual are available for the 3390. Please download them from the HIOKI website.

Please purchase separately-sold voltage cord and current sensor for measurements. A HIOKI-issued PC card is also necessary in order to save measured data

#### Combination example 1.

General measurements (Three-phase three-wire (3P3W3M) single-circuit) 3390 × 1 + 9438-50 (voltage cord) × 3 + 9272-10 (200 A sensor) × 3 + 9729 (1 GB card) × 1 + 9794 case x 1











## • Combination example 2.

Inverter input and output evaluation and measurements (Three-phase there-wire (3P3W2M) two-circuit)

3390 × 1 + 9438-50 (voltage cord) × 4 + 9709 (500 A sensor) × 4 + 9729 (1 GB card) × 1 + 9794 case × 1











#### Combination example 3.

Motor evaluation and measurements (DC input / three-phase motor evaluation (DC, 3P3W3M measurements))

3390 × 1 +9793 (motor and D/A option) + 9438-50 (voltage cord) × 4 + 9709 (500 A sensor) ×  $4 + 9729 (1 \text{ GB card}) \times 1$ 











HIOKI E.E. CORPORATION

#### **HEAD OFFICE:**

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

#### HIOKI USA CORPORATION:

6 Corporate Drive, Cranbury, NJ 08512 USA TEL +1-609-409-9109 / FAX +1-609-409-9108 E-mail: hioki@hiokiusa.com

HIOKI (Shanghai) Sales & Trading Co., Ltd.: 1608-1610 Shanghai Times Square Office, 93 Huai Hai Zhong Road, Shanghai, P.R.China POSTCODE: 200021 TEL +86-21-6391-0090/0092 FAX +86-21-6391-0360 E-mail: info-sh@hioki.com.cn

Beijing Office:
A-2602 Freetown, 58 Dong San Huan Nan Road
Beijing, P.R.China POSTCODE: 100022
TEL +86-10-5867-4080/4081 FAX +86-10-5867-4090 E-mail: info-bj@hioki.com.cn

#### Guangzhou Office:

Room A-3206, Victory PlazaServices Center, No.103, Tiyuxi Road, Guangzhou, P.R.China POSTCODE:510620 TEL +86-20-38392673/2676 FAX +86-20-38392679 E-mail: info-gz@hioki.com.cn

DISTRIBUTED BY